

# WATER VALVE

AC1GM-01

## ON-VEHICLE INSPECTION

1. **WARM UP ENGINE**
2. **DISCONNECT WATER VALVE CONTROL CABLE**
3. **INSPECT WATER VALVE OPERATION**
  - (a) Check that warm air is blown out the vent when the water valve lever is moved to "WARM" position.
  - (b) Check that cool air is blown out of the vent when the water valve is moved to the "COOL" position.If operation is not as specified, replace the water valve.
4. **CONNECT WATER VALVE CONTROL CABLE**

After connection, adjust the control cable.