


REASSEMBLY


INSTALL STARTER CENTER BEARING CLUTCH SUB-ASSEMBLY

- (a) Install the drive lever set pin onto the starter center bearing clutch.
- (b) Install the starter center bearing clutch with drive lever set pin to the starter drive housing.



INSTALL PLANET GEAR 2.

- (a) Apply grease to the planet gears and planet shaft
- (b) Install the 3 planet gears.




INSTALL STARTER ARMATURE PLATE 3.

- (a) Insert the starter armature plate into the starter yoke.
- (b) Align the cutout of the plate with the inside protrusion of the starter yoke, and install the plate.

INSTALL STARTER ARMATURE ASSEMBLY

- (a) Apply grease to the washer plate and armature
- (b) Install the armature shaft onto the starter commutator end frame.
- (c) Using snap ring pliers, install the plate washer and snap ring.



5.0 mm

(d) Using a vernier caliper, measure the snap ring length.

Maximum length:


5.0 mm (0.197 in)

If the length is greater than the maximum, replace

the snap ring with a new one. **INSTALL STARTER COMMUTATOR END FRAME** 5. COVER


A058810E03

ST




6. INSTALL STARTER YOKE ASSEMBLY

- (a) Align the rubber of the starter commutator end frame with the cutout of the starter yoke.
- (b) Install the starter yoke onto the starter commutator end frame.



(c) Align the key located on the starter yoke with the keyway of the starter housing.




(d) Install the starter yoke and commutator end frame with the 2 through bolts.

Torque: 6.0 N*m (61 kgf*cm, 53 in.*lbf)



- (a) Apply grease to the plunger and hook.
- (b) Put the plunger hook of the magnet switch body on the drive lever.





- (c) Install the plunger and return spring as shown in the illustration.
- (d) Install the magnet switch body with the 2 screws. Torque: 7.5 N*m (76 kgf*cm, 66 in.*lbf)

