


DTC	B0126/27	Seat Belt Buckle Switch LH Circuit Malfunction
-----	----------	--

DESCRIPTION

The seat belt buckle switch LH circuit consists of the center airbag sensor assembly and the front seat inner belt assembly LH (seat belt buckle switch LH).  
DTC B0126/27 is recorded when a malfunction is detected in the seat belt buckle switch LH circuit.


DTC No.	DTC detection Condition	Trouble Area
B0126/27	<ul style="list-style-type: none"><li>Short circuit in front seat inner belt assembly LH wire harness (to ground)</li><li>Short circuit in front seat inner belt assembly LH wire harness (to B+)</li><li>Open circuit in LBE+ wire harness or LBE- wire harness of front seat inner belt assembly LH</li><li>Front seat inner belt assembly LH assembly</li><li>Center airbag sensor assembly</li></ul>	<ul style="list-style-type: none"><li>front seat inner belt assembly LH (seat belt buckle switch LH)</li><li>Center airbag sensor assembly</li><li>Floor wire</li></ul>

WIRING DIAGRAM



1	CHECK FLOOR WIRE (TO B+)
---	--------------------------

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the center airbag sensor assembly and the front seat inner belt assembly LH.
- (d) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.



(e) Measure the voltage according to the value(s) in the table below.

**Standard voltage**

Tester Connection (Connector "B")	Condition	Specified Condition
A9-11 (LBE+) - Body ground	Ignition switch ON	Below 1 V
A9-7 (LBE-) - Body ground		

**NG**

**REPAIR OR REPLACE FLOOR WIRE**


**OK**

**2 CHECK FLOOR WIRE (TO GROUND)**

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.

**RS**

RS



(c) Measure the resistance according to the value(s) in the table below.

**Standard resistance**

Tester Connection (Connector "B")	Specified Condition
A9-11 (LBE+) - Body ground	1 MΩ or higher
A9-7 (LBE-) - Body ground	

NG


REPAIR OR REPLACE FLOOR WIRE

OK

3

**CHECK FRONT SEAT INNER BELT ASSEMBLY**

- (a) Connect the connector to the front seat inner belt assembly LH.
- (b) Unfasten the seat belt from the front seat inner belt LH.



- (c) Measure the resistance according to the value(s) in the table below.

**Standard resistance**

Tester Connection (Connector "B")	Specified Condition
A9-11 (LBE+) - A)-7 (LBE-)	100 to 500 $\Omega$

**NG**


**REPLACE FRONT SEAT INNER BELT ASSEMBLY LH**

**RS**

**OK**

**4**

**CHECK FRONT SEAT INNER BELT ASSEMBLY LH**



- (a) Fasten the seat belt to the front seat inner belt LH.  
 (b) Measure the resistance according to the value(s) in the table below.

**Standard resistance**

Tester Connection (Connector "B")	Specified Condition
A9-11 (LBE+) - A)-7 (LBE-)	1.0 to 1.6 k $\Omega$

**NG**

**REPLACE FRONT SEAT INNER BELT ASSEMBLY LH**

**OK**


## 5 CHECK CENTER AIRBAG SENSOR ASSEMBLY

RS

- Connect the connector to the center airbag sensor assembly.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the stored DTCs in the memory (see page RS-21).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check for the DTCs (see page RS-21).

**OK:****DTC B0126/27 is not output.****HINT:**

Codes other than code B0126/27 may be output at this time, but they are not related to this check.

**NG**
**REPLACE CENTER AIRBAG SENSOR ASSEMBLY**
**OK**

## PROBLEM SYMPTOMS SIMULATION