

DTC	B1180/17	Short in Driver Side Squib 2nd Step Circuit
-----	----------	---

DESCRIPTION


The driver side squib (2nd step) circuit consists of the center airbag assembly, the spiral cable sub-assembly and the steering pad.

This circuit instructs the SRS to deploy when deployment conditions are met.

DTC B1180/17 is recorded when a short circuit is detected in the driver side squib (2nd step) circuit.

DTC No.	DTC Detection Condition	Trouble Area
B1180/17	<ul style="list-style-type: none">Short circuit between D2+ wire harness and D2- wire harness of driver side squib (2nd step)Driver side squib (2nd step) malfunctionSpiral cable sub-assembly malfunctionCenter airbag sensor assembly malfunction	<ul style="list-style-type: none">Steering pad (driver side squib, 2nd step)Spiral cable sub-assemblyCenter airbag sensor assemblyInstrument panel wire

WIRING DIAGRAM



1 CHECK SPIRAL CABLE SUB-ASSEMBLY

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the steering pad.
- (d) Check that the spiral cable sub-assembly connector (on the steering pad side) is not damaged.

OK:


Lock button is not disengaged, or claw of lock is not deformed or damaged.

NG**REPLACE SPIRAL CABLE SUB-ASSEMBLY****OK****2 CHECK DRIVER SIDE SQUIB (2ND STEP) CIRCUIT (CENTER AIRBAG SENSOR ASSEMBLY - STEERING PAD)**

- (a) Disconnect the connector from the center airbag sensor assembly.
- (b) Release the activation prevention mechanism built into connector "B" (see page [RS-12](#)).
- (c) Measure the resistance according to the value(s) in the table below.


Standard resistance

Tester Connection (Connector "E")	Specified Condition
D2+ - D2-	1 MΩ or higher

NG**Go to step 5****OK****3 CHECK CENTER AIRBAG SENSOR ASSEMBLY**

- (a) Connector the connector to the center airbag sensor assembly.

RS



OK

- (b) Connector the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (c) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (d) Clear the stored DTCs in the memory (see page RS-21).
- (e) Turn the ignition switch to the LOCK position.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Check for the DTCs (see page RS-21).

OK:**DTC B1180/17 is not output.****HINT:**


Codes other than code B1180/17 may be output at this time, but they are not related to this check.

NG

REPLACE CENTER AIRBAG SENSOR ASSEMBLY

4**CHECK STEERING PAD (DRIVER SIDE SQUIB, 2ND STEP)**

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Connect the connectors to the steering pad.
- (d) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (e) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (f) Clear the stored DTCs in the memory (see page RS-21).
- (g) Turn the ignition switch to the LOCK position.
- (h) Turn the ignition switch to the ON position, and wait for at least 60 seconds.



OK

- (i) Check for the DTCs (see page RS-21).

OK:

B1180/17 is not output.

HINT:

Codes other than code B1180/17 may be output this time, but they are not related to this check.

NG

REPLACE STEERING PAD

RS


PROBLEM SYMPTOMS SIMULATION**5****CHECK INSTRUMENT PANEL WIRE**

- (a) Disconnect the instrument panel wire connector from the spiral cable sub-assembly.

HINT:

The activation prevention mechanism of connector "B" has already been released.

RS



OK

6


CHECK SPIRAL CABLE SUB-ASSEMBLY

- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance

Tester Connection (Connector "C")	Specified Condition
A13-4 (D2+) - A13-3 (D2-)	1 MΩ or higher

NG REPAIR OR REPLACE INSTRUMENT PANEL WIRE



- (a) Release the activation prevention mechanism built into connector "D" (see page RS-12).
- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance

Tester Connection (Connector "E")	Specified Condition
D2+ - D2-	1 MΩ or higher

NG REPLACE SPIRAL CABLE SUB-ASSEMBLY

OK

PROBLEM SYMPTOMS SIMULATION

RS