


FRONT SUSPENSION NO. 1 LOWER ARM (for Manual Transaxle)

COMPONENTS



REMOVAL

HINT:



Remove the suspension lower arm RH (Manual Transaxle) following the same procedures as the suspension lower arm LH (Automatic Transaxle).

1. REMOVE FRONT WHEEL
2. DISCONNECT FRONT SUSPENSION NO. 1 LOWER ARM SUB-ASSEMBLY LH (See page [SP-16](#))
3. DISCONNECT FRONT STABILIZER BAR (See page [SP-16](#))
4. REMOVE FRONT SUSPENSION NO. 1 LOWER ARM SUB-ASSEMBLY LH

- (a) Remove the 2 bolts, nut and lower arm.

NOTICE:

Do not turn the nut.



INSPECTION

1. INSPECT FRONT SUSPENSION NO. 1 LOWER ARM SUB-ASSEMBLY LH
 - (a) As shown in the illustration, flip the ball joint stud back and forth 5 times before installing the nut.
 - (b) Using a torque wrench, turn the nut continuously at a rate of 2 to 4 seconds per turn and take the torque reading on the fifth turn.


HINT:


A bolt without a torque specification is shown in the standard bolt chart (see page [SS-32](#)).

INSTALLATION

1. TEMPORARILY INSTALL FRONT SUSPENSION NO. 1 LOWER ARM SUB-ASSEMBLY LH
 - (a) Temporarily install the lower arm with the 2 bolts and nut.
2. CONNECT FRONT SUSPENSION NO. 1 LOWER ARM SUB-ASSEMBLY LH (See page [SP-19](#))
3. CONNECT FRONT STABILIZER BAR (See page [SP-19](#))
4. INSTALL FRONT WHEEL

Torque: 103 N*m (1,050 kgf*cm, 76 ft.*lbf)





5. FULLY TIGHTEN FRONT SUSPENSION NO. 1 LOWER ARM SUB-ASSEMBLY LH

- (a) Install the lower suspension arm with the 2 bolts.
Torque: 88 N*m (900 kgf*cm, 65 ft.*lbf) for bolt A
132 N*m (1,350 kgf*cm, 97 ft.*lbf) for bolt B

NOTICE:

Do not turn the nut.

6. INSPECT AND ADJUST FRONT WHEEL ALIGNMENT

- (a) Inspect and adjust the front wheel alignment (see page [SP-2](#)).