












# SUPPLEMENTAL RESTRAINT SYSTEM

## SST

	09082-00700	SRS Airbag Deployment Tool	-
	09082-00780	Airbag Deployment Wire Sub-harness No.6	-
	09082-00802	Airbag Deployment Wire Sub-Harness No. 8	-
	(09082-10801)	Wire A	-
	(09082-30801)	Wire C	-
	09843-18030	Tacho-pulse Pickup Wire No.2	-
	09843-18040	Diagnosis Check Wire No.2	-

PP

# RECOMMENDED TOOLS

	<p>09042-00010</p>	<p>Torx Socket T30</p>	<p>-</p>
	<p>09042-00020</p>	<p>Torx Socket T40</p>	<p>-</p>
	<p>09082-00040</p>	<p>TOYOTA Electrical Tester</p>	<p>-</p>
	<p>(09083-00150)</p>	<p>Test Lead Set</p>	<p>-</p>

PP