

INSTALLATION

HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- A bolt without a torque specification is shown in the standard bolt chart (see page [SS-2](#)).

1. INSTALL BODY ROCKER PANEL MOULDING LH

- (a) Attach the 6 clips to install the moulding.
- (b) Install the 2 bolts, 2 moulding end covers and 8 retainers.

