








# CLUTCH

## SST

	<p>09023-00101</p>	<p>Union Nut Wrench 10 mm</p>	<p>-</p>
	<p>09301-00210</p>	<p>Clutch Guide Tool</p>	<p>-</p>
	<p>09333-00013</p>	<p>Universal Joint Bearing Remover &amp; Replacer</p>	<p>-</p>

**RECOMMENDED TOOLS**

	<p>09031-00030</p>	<p>Pin Punch</p>	<p>-</p>
	<p>09040-00011</p>	<p>Hexagon Wrench Set</p>	<p>-</p>
	<p>09082-00040</p>	<p>TOYOTA Electrical Tester</p>	<p>-</p>
	<p>09905-00013</p>	<p>Snap Ring Pliers</p>	<p>-</p>

PP