
































# POWER STEERING

## SST

	09023-12701	Union Nut Wrench 17mm	
	09023-38201	Union Nut Wrench 12mm	
	09240-00020	Wire Gauge Set	
	09521-24010	Rear Axle Shaft Puller	
	09612-00012	Rack & Pinion Steering Rack Housing Stand	
	09612-24014	Steering Gear Housing Overhaul Tool Set	
	(09613-22011)	Steering Rack Shaft Bushing Puller	
	09616-00011	Steering Worm Bearing Adjusting Socket	
	09630-00014	Power Steering Gear Housing Overhaul Tool Set	
	(09631-00132)	Vane Pump Bracket	
	09631-10041	Steering Rack Cover D	

	<p>09631-12071</p>	<p>Steering Rack Oil Seal Test Tool</p>	
	<p>(09633-00010)</p>	<p>Packing</p>	
	<p>09640-10010</p>	<p>Power Steering Pressure Gauge Set</p>	
	<p>(09641-01010)</p>	<p>Gauge Assembly</p>	
	<p>(09641-01030)</p>	<p>Attachment B</p>	
	<p>(09641-01060)</p>	<p>Attachment E</p>	
	<p>09670-00010</p>	<p>Front Crossmember Guide Tool</p>	
	<p>09922-10010</p>	<p>Variable Open Wrench</p>	
	<p>09950-60010</p>	<p>Replacer Set</p>	
	<p>(09951-00200)</p>	<p>Replacer 20</p>	
	<p>(09951-00210)</p>	<p>Replacer 21</p>	
	<p>(09951-00240)</p>	<p>Replacer 24</p>	

PP

	(09951-00280)	Replacer 28	
	(09951-00340)	Replacer 34	
	(09951-00370)	Replacer 37	
	(09952-06010)	Adapter	
	09950-70010	Handle Set	
	(09951-07100)	Handle 100	
	(09951-07200)	Handle 200	
	(09951-07360)	Handle 360	