

REMOVAL

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**

CAUTION:

Wait at least 90 seconds after disconnecting the cable from the negative (-) battery terminal to prevent airbag and seat belt pretensioner activation.

2. **REMOVE GLOVE COMPARTMENT DOOR ASSEMBLY (See page [IP-19](#))**

3. **REMOVE ECM**

- (a) Disconnect the 4 ECM connectors.
- (b) Remove the 2 bolts and ECM.
- (c) Remove the 2 screws and ECM bracket.
- (d) Remove the 2 screws and No. 2 ECM bracket.
- (e) Remove the 2 screws and No. 3 ECM bracket.

INSTALLATION

1. INSTALL ECM

- (a) Install the No. 3 ECM bracket with the 2 screws.
- (b) Install the No. 2 ECM bracket with the 2 screws.
- (c) Install the ECM bracket with the 2 screws.
- (d) Install the ECM with the 2 bolts.

Torque: 3.0 N*m (31 kgf*cm, 27 in.*lbf)

- (e) Connect the 4 ECM connectors.

2. INSTALL GLOVE COMPARTMENT DOOR ASSEMBLY (See page [IP-26](#))

3. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL