

FUEL TANK CAP

ON-VEHICLE INSPECTION

- 1. CHECK FUEL TANK CAP ASSEMBLY
 - (a) Visually check if the cap or gasket is deformed or damaged.

EC