

PROBLEM SYMPTOMS TABLE

HINT:

Use the table below to help determine the cause of the problem symptom. The potential causes of the symptoms are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.

Audio and visual system

Symptom	Suspected area	See page
No sound can be heard only from front speaker.	1. Front No. 1 speaker assembly	AV-5
	2. Wire harness	-
No sound can be heard only from tweeter speaker.	1, Front No. 2 speaker assembly	AV-7
	2. Wire harness	-
No sound can be heard only from rear speaker.	1. Rear speaker assembly	AV-9
	2. Wire harness	-