INSTALLATION

HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- 1. INSTALL FRONT DOOR GLASS WEATHERSTRIP ASSEMBLY OUTER LH
 - (a) Attach the claws to install the weatherstrip as shown in the illustration.
- 2. INSTALL OUTER REAR VIEW MIRROR SUB-ASSEMBLY LH (See page MI-8)
- 3. INSTALL FRONT DOOR TRIM BOARD SUB-ASSEMBLY LH (See page ED-18)
- 4. INSTALL POWER WINDOW REGULATOR MASTER SWITCH ASSEMBLY (See page ED-16)
- 5. INSTALL DOOR PULL HANDLE (See page ED-18)
- 6. INSTALL FRONT DOOR LOWER FRAME BRACKET GARNISH LH (See page ED-19)
- 7. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

