

## PROBLEM SYMPTOMS TABLE

### HINT:

Use the table below to help determine the cause of the problem symptom. The potential causes of the symptoms are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.

### Horn system

Symptom	Suspected area	See page
Horn does not sound	1. HORN fuse	<a href="#">HO-4</a>
	2. HORN relay	<a href="#">HO-4</a>
	3. High pitched horn	<a href="#">HO-8</a>
	4. Low pitched horn	<a href="#">HO-5</a>
	5. Steering pad switch	
	6. Spiral cable	