

PROBLEM SYMPTOMS TABLE

HINT:

Use the table below to help determine the cause of the problem symptom. The potential causes of the symptoms are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.

Wiper and washer system



Symptom	Suspected area	See page
Front wipers do not operate.	1. WIPER fuse	-
	2. Windshield wiper switch assembly	WW-22
	3. Windshield wiper motor assembly	WW-9
	4. Wire harness	-
Front wipers do not operate in the LO or HI position.	1. Windshield wiper switch assembly	WW-22
	2. Windshield wiper motor assembly	WW-9
	3. Wire harness	-
Front wipers do not operate in the INT position.	1. Windshield wiper switch assembly	WW-22
	2. Windshield wiper motor assembly	WW-9
	3. Wire harness	-
Front washer motor does not operate.	1. WIPER fuse	-
	2. Windshield wiper switch assembly	WW-22
	3. Washer motor	WW-25
	4. Wire harness	-
Front wiper do not operate when washer switch is in the ON position.	1. Windshield wiper switch assembly	WW-22
	2. Windshield wiper motor assembly	WW-9
	3. Wire harness	-
Rear wiper and washers do not operate.	1. WIPER fuse	-
	2. Rear wiper switch	WW-22
	3. Wire harness	-
Rear washer motor does not operate.	1. WASH fuse	-
	2. Rear washer switch	WW-22
	3. Washer motor	WW-25
	4. Wire harness	-
Rear washers do not operate when washer switch is in the ON position.	1. Rear wiper switch	WW-22
	2. Rear wiper motor	WW-16
	3. Wire harness	-
Washer fluid does not flow.	1. Washer hose and nozzle	-
When the wiper switch is off, the wiper blade does not retract or retracts in the wrong position.	1. Windshield wiper motor assembly (Wiper arm and blade set position)	WW-9
The wiper blade is in contact with the body.	1. Windshield wiper motor assembly (Wiper arm and blade set position)	WW-9