

# 2006 xB

# ELECTRICAL WIRING DIAGRAM

	Section Code	Page
INTRODUCTION .....	A .....	2
HOW TO USE THIS MANUAL .....	B .....	3
TROUBLESHOOTING .....	C .....	12
ABBREVIATIONS .....	D .....	17
GLOSSARY OF TERMS AND SYMBOLS .....	E .....	18
RELAY LOCATIONS .....	F .....	20
ELECTRICAL WIRING ROUTING .....	G .....	28
SYSTEM CIRCUITS .....	H .....	37
GROUND POINT .....	I .....	154
POWER SOURCE (Current Flow Chart) .....	J .....	158
CONNECTOR LIST .....	K .....	164
PART NUMBER OF CONNECTORS .....	L .....	174
OVERALL ELECTRICAL WIRING DIAGRAM .	M .....	176