

## L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Condenser Fan Resistor	90980-10928	D 4	Door Lock Control Relay	90980-12203
A 2	A/C Magnetic Valve	90980-11156	D 5	Door Courtesy SW Front LH	90980-10871
A 3	A/T Indicator Light SW	90980-11784	D 6	Door Courtesy SW Front RH	
	Back-Up Light SW		D 7	Door Courtesy SW Rear LH	
	Park/Neutral Position SW		D 8	Door Courtesy SW Rear RH	
A 4	ABS Speed Sensor Front LH	90980-11002	D 9	Door Key Lock and Unlock SW Front LH	90980-11858
A 5	ABS Speed Sensor Front RH				
A 6	A/C Thermistor	90980-11918		Door Lock Motor Front LH	
A 7	A/T Shift Lever Illumination	90980-10795	D 10	Door Unlock Detection SW Front LH	
	O/D Main SW		D 10	Door Key Lock and Unlock SW Front RH	
A 8	Air Inlet Servo Motor	90980-11989	D 11	Door Lock Motor Front RH	90980-12122
A 9	Airbag Sensor Assembly	90980-11869		D 11	
A 10	Airbag Sensor Assembly	90980-11872	D 12	Door Lock Control SW Front RH	90980-10797
A 11	Airbag Sensor Assembly	90980-11867	D 13	Door Lock Motor Rear LH	90980-11019
A 12	Airbag Squib (Front Passenger's Airbag Assembly)	90980-12160	D 14	Door Lock Motor Rear RH	
	Airbag Squib (Steering Wheel Pad)		E 1	Electronically Controlled Transmission Solenoid	90980-11658
A 14	Antenna Amplifier	90980-10870	E 2	Engine Coolant Temp. Sensor	90980-10735
A 15	ABS Speed Sensor Rear LH	90980-10859	E 3	Engine Control Module	90980-12142
A 16	ABS Speed Sensor Rear RH		E 4	Engine Control Module	90980-12146
A 17	A/C Amplifier	90980-12410	E 5	Engine Control Module	90980-12144
A 18	A/C Amplifier	90980-12200	E 6	Engine Control Module	90980-12145
B 1	Back-Up Light SW	90980-11250	F 1	Front Airbag Sensor LH	90980-12401
B 2	Brake Fluid Level Warning SW	90980-11207	F 2	Front Airbag Sensor RH	
B 3	Blower Motor	90980-10214	F 3	Front Fog Light LH	90980-11096
B 4	Blower Resistor	90980-11136	F 4	Front Fog Light RH	
B 5	Back Door Courtesy SW	90980-10795	F 5	Front Parking Light LH	90980-11020
	Back Door Lock Motor			Front Turn Signal Light LH	
B 6	Back Door Opener SW	90980-12063	F 6	Front Parking Light RH	
B 7	Buckle SW LH	90980-12257		Front Turn Signal Light RH	
	Seat Position Sensor		F 7	Front Wiper Motor	90980-11599
B 8	Buckle SW RH	90980-11020	F 8	Fusible Link Block	-
	Occupant Detection Sensor		F 9	Fusible Link Block	90980-11775
C 1	Camshaft Position Sensor	90980-10947	F 10	Front Fog Light Relay	82660-20340
C 2	Camshaft Timing Oil Control Valve	90980-11162	F 11	Front Fog Light SW	90980-10489
C 3	Crankshaft Position Sensor	90980-12028	F 12	Front Door Speaker LH	90980-10935
C 4	Cigarette Lighter	90980-10760	F 13	Front Door Speaker RH	
C 5	Clutch Start SW	90980-10825	F 14	Fuel Pump	90980-11077
C 6	Combination Meter	90980-12169		Fuel Sender	
C 7	Combination SW	90980-12183	F 15	Fuse Block	82610-20080
C 8	Combination SW	90980-12007	G 1	Generator	90980-11349
C 9	Combination SW	90980-12008	G 2	Generator	90980-09373
C 10	Canister Pump Module	90980-12380	H 1	Headlight LH	90980-11314
D 1	Data Link Connector 3	90980-11978	H 2	Headlight RH	
D 2	Defroster Mode Detection SW	90980-10795	H 3	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869
	Inlet Air Position Detection SW		H 4	Horn (High)	90980-10619
D 3	Door Control Receiver	90980-11909	H 5	Horn (Low)	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
H 6	Headlight Relay	82660-20340	P 9	Power Window Motor Front LH	90980-10797
H 7	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028	P10	Power Window Motor Front RH	
H 8	High Mounted Stop Light	90980-11148	P11	Power Window Motor Rear LH	90980-10860
I 1	Idle Air Control Valve	90980-11145	P12	Power Window Motor Rear RH	
I 2	Ignition Coil and Igniter No.1	90980-11885	P13	Pretensioner LH	90980-12253
I 3	Ignition Coil and Igniter No.2				
I 4	Ignition Coil and Igniter No.3				
I 5	Ignition Coil and Igniter No.4				
I 6	Injector No.1	90980-11875	R 1	Radiator Fan Motor	90980-10928
I 7	Injector No.2				
I 8	Injector No.3				
I 9	Injector No.4				
I10	Ignition SW	90980-11778	R 2	Radio and Player	90980-10997
I11	Integration Control and Panel	90980-10908	R 3	Radio and Player	90980-10996
I12	Integration Control and Panel	90980-11013	R 4	Rear Window Defogger Relay	82660-20340
I13	Integration Control and Panel	90980-10993	R 5	Remote Control Mirror SW	90980-11657
I14	Interior Light	90980-10935	R 6	Rheostat	90980-10797
I15	Integration Control and Panel	90980-10908	R 7	Rear Combination Light LH	
J 1	Junction Connector	90980-11542	R 8	Rear Combination Light RH	90980-11250
J 2	Junction Connector	90980-11661	R 9	Rear Side Marker Light LH	
J 3	Junction Connector				
J 4	Junction Connector	90980-11915	R10	Rear Side Marker Light RH	90980-10935
J 5	Junction Connector				
J 6	Junction Connector	90980-11661	R11	Rear Speaker LH	90980-11853
J 7	Junction Connector				
J 8	Junction Connector	90980-11542	R12	Rear Speaker RH	90980-10860
J 9	Junction Connector				
J10	Junction Connector				
K 1	Knock Sensor (Bank 1)		90980-11875	R13	Rear Window Defogger
L 1	License Plate Light	90980-10825	R14	Rear Window Defogger	
M 1	Mass Air Flow Meter	90980-11317	R15	Rear Wiper Motor	90980-12460
N 1	Noise Filter (Ignition)	90980-10843	R16	Remote Control Mirror LH	90980-11162
N 2	Noise Filter (Rear Window Defogger No.1)	90980-10916	R17	Remote Control Mirror RH	
N 3	Noise Filter (Fuel Pump)				
N 4	Noise Filter (Stop Light and Rear Window Defogger No.2)	90980-11542	R18	Radio and Player	90980-11162
O 1	Oil Pressure SW	90980-11363	S 1	Side Turn Signal Light LH	90980-12297
O 2	Option Connector (TVIP)	90980-10871	S 2	Side Turn Signal Light RH	
O 3	Option Connector (IPOD Unit)	90980-12553	S 3	Skid Control ECU with Actuator	90980-09506
O 4	Option Connector (Radio and Player)	90980-12423	S 4	Starter	90980-11400
P 1	Power Steering Oil Pressure Sensor	90980-10845	S 5	Starter	90980-11909
P 2	Pressure Sensor				
P 3	Parking Brake SW	90980-10871	S 6	Shift Lock Control SW	90980-12162
P 5	PTC Heater	90980-10903	S 7	Steering Sensor	90980-11118
P 6	Power Window Control SW Front RH	90980-10789	S 8	Stop Light SW	82824-21030
P 7	Power Window Control SW Rear LH				
P 8	Power Window Control SW Rear RH				
			S 9	Stereo Jack Adapter	90980-11261
			T 1	Throttle Position Sensor	90980-11156
			T 2	Turbine Speed Sensor	90980-10631
			T 3	TRAC OFF SW	90980-10860
			T 4	Tweeter LH	
			T 5	Tweeter RH	90980-11156
			U 1	Unlock Warning SW	90980-10906
			V 1	VSV (Purge)	90980-10981
			V 2	VSC Buzzer	90980-11904
			W 1	Washer Motor	
			Y 1	Yaw Rate Sensor	