BULLETIN

July 8, 2005

Title:

DOME FUSE INSTALLATION
DURING PDS

Models:

'05 - '06 Scion xB



Introduction


To minimize battery discharge during transportation and storage, the DOME fuse has been removed at the assembly plant.

Applicable Vehicles

2005 – 2006 model year Scion xB vehicles.

Installation Procedure


1. The removed DOME fuse (15A) is stored in the blank space of the Relay Block in the Engine Compartment.



During Pre-Delivery Service (PDS), install the DOME fuse (15A) in the Relay Block as shown.

NOTE:

If the vehicle is stored at the dealership for a long period of time after PDS, disconnect the negative (–) battery terminal to prevent battery discharge. Refer to TSB PG017–02, "Battery Maintenance for In–Stock Vehicles & Pre–Delivery," for battery maintenance information.



Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	_	_	_	_

