




AIR CONDITIONING SYSTEM

PRECAUTION



1. **DO NOT HANDLE REFRIGERANT IN AN ENCLOSED AREA OR NEAR AN OPEN FLAME**
2. **ALWAYS WEAR PROTECTIVE GLASSES**

3. **AVOID SKIN OR EYE CONTACT WITH LIQUID REFRIGERANT**

If liquid refrigerant comes in contact with your eyes or skin:

- (a) Rinse the area thoroughly with cold water.

CAUTION:

Do not rub your eyes or skin.

- (b) Apply clean petroleum jelly to the skin.
- (c) Go immediately to a hospital or see a physician for professional treatment.

4. **NEVER HEAT CONTAINER OR EXPOSE IT TO OPEN FLAME**

5. **DO NOT DROP OR STRIKE CONTAINER OF REFRIGERANT**

6. **DO NOT OPERATE COMPRESSOR WITHOUT ENOUGH REFRIGERANT IN REFRIGERANT SYSTEM**

If there is not enough refrigerant in the refrigerant system, oil lubrication will be insufficient and the compressor may burn out. Care should be taken to avoid this.

7. **DO NOT OPEN HIGH PRESSURE MANIFOLD VALVE WHILE COMPRESSOR IS OPERATING**

Only open and close the low pressure valve. If the high pressure valve is opened, refrigerant flows in the reverse direction and causes the charging cylinder to rupture.

8. **BE CAREFUL NOT TO OVERCHARGE SYSTEM WITH REFRIGERANT**


Overcharged refrigerant will cause problems such as insufficient cooling, poor fuel economy, engine overheating, etc.


9. **DO NOT OPERATE ENGINE AND COMPRESSOR WITHOUT REFRIGERANT IN REFRIGERANT SYSTEM**


NOTICE:

This may damage the inside of the compressor because the compressor parts move regardless of whether the A/C system is turned on or off.

PARTS LOCATION







P

E117559E01